



USER MANUAL



LiFePO₄ Battery Energy Storage System



Please read instructions carefully before use

Table of Contents

Overview	1
Scope	1
Intended Audience	1
Manual Usage	1
Product Introduction	1
Introduction	1
Safety Instructions	2
Labeling Explanation	2
Installation Tools	2
Precautions	3
Manual Storage	3
Label Protection	3
Safety Warning Labels	3
Personnel Requirements	3
Power-On Measurement	4
Measuring Instruments	4
Maintenance and Inspection	4
Overview of Main Components	5
Product Introduction	6
Overview	6
Advantages	6
Product Appearance	7
Product Model	7
Port Panel	8
Principle and Structure	9
Operating Principle	9
Connection Structure	9
Battery Installation and Wiring	10
Tool Preparation for Installation	10
Installation Preparation	10
Installation Notes	10
Installation Steps	11
Electrical Connection	12
Parallel Wiring	13
Debugging	14
RS485 & CAN Port Definition	14
Upper Computer Software Operation Guide	15
Operation Guidance for Button Display Screen	18
Operation Guidance for Touchable Display Screen	19
Power-On Sequence	21
Common Issues and Solutions	21
Inverter Matching Information	22
Maintenance	23

Overview

◆ Scope

This user manual provides information, operating instructions, and maintenance guidelines for the low-voltage residential energy storage battery series. The residential energy storage series is a lithium battery system developed by designed to be compatible with various inverter brands available in the market.

◆ Intended Audience

This manual is intended for professional technical personnel involved in the installation, operation, and maintenance of lithium batteries, as well as end-users seeking technical information.

◆ Manual Usage

1. Before using the product, carefully review this user manual and keep it in a readily accessible location.
2. All information in this user manual, including images and symbols, is proprietary to . Unauthorized use of any part or all of the content is strictly prohibited for individuals outside the company.
3. Considering the potential for updates and corrections to the manual content, users are advised to use the provided documentation as a reference. For the latest user manual, please refer to the product documentation provided or contact customer service through the official website.

Product Introduction

◆ Introduction

1. The residential energy storage series is a battery module developed by for low-voltage lithium battery systems, primarily applied in the field of residential energy storage. It can achieve high-precision multi-cell voltage and temperature acquisition.
2. The module adopts a passive balancing method, with a maximum balancing current of up to 300mA, improving the overall lifespan of the battery pack.
3. The module features external communication interfaces using CAN, RS485, and dry contact communication methods, allowing communication in parallel for up to 16 batteries.
4. Embedded BMS system effectively monitors phenomena such as over-temperature, over-voltage, and over-current, reducing the risk of battery damage or even fire, ensuring the safety of life and property.
5. This manual introduces the types, sizes, performance, technical characteristics, warnings, and precautions of lithium battery systems. This specification is only applicable to the battery systems provided by .

Safety Instructions

◆ Labeling Explanation

To ensure user safety during product use, relevant labeling information with appropriate symbols is provided in this manual. The following lists symbols that may be used in this manual, so please read carefully.

Icon	Description
	Signifies a low-level potential hazard. Failure to avoid may result in minor or moderate injury to personnel.
	Indicates the presence of high voltage inside the battery module. Touching may lead to electric shock hazards.
	This is the ground protection port (PE). It should be securely grounded to ensure the safety of operating personnel.

◆ Installation Tools

Prior to installation, prepare the following tools:

Category	Description		
General Tools	 Multimeter	 Protective gloves	 Insulated safety shoes
	 Protective clothing	 Safety goggles	 Antistatic wrist strap
Installation Tools	 Electric screwdriver	 Socket wrench	 Wire stripper
	 Phillips screwdriver (M4/M6)	 Electric drill	 Hammer

Precautions

◆ Manual Storage

1. This manual covers crucial information for the residential energy storage series. Prior to operating the product, carefully read this manual as it provides essential assistance in acquainting you with the product.
2. Store this manual securely for the convenience of relevant installation and maintenance personnel to refer to during operations.
3. Strictly follow the descriptions in this manual when operating the residential energy storage series to avoid equipment damage, injuries, property loss, and other potential issues.

◆ Label Protection

1. Warning labels on the residential energy storage series contain crucial safety operation information. It is strictly prohibited to intentionally tear or damage them!
2. The product has a nameplate on the casing, providing essential parameter information. It is strictly prohibited to intentionally tear or damage it!

◆ Safety Warning Labels

When conducting installation, routine maintenance, inspections, etc., on the Home Energy Storage Series, to prevent unauthorized individuals from approaching, engaging in improper operations, or accidents, adhere to the following conventions:

1. Erect clear signage at the switch locations of the products to prevent accidents caused by accidental closing.
2. Set warning signs or establish safety warning tape near the operating area to prevent unrelated personnel from approaching.
3. After maintenance or inspection, conduct a thorough on-site safety check.

◆ Personnel Requirements

1. Only personnel with relevant professional qualifications are allowed to perform various operations on this product.
2. Operating personnel should be thoroughly familiar with the composition and working principles of the entire residential energy storage series system.
3. Operating personnel should be fully acquainted with the "User Manual" for this product.

Precautions

◆ Power-On Measurement



After the energy storage battery is installed, there is a high voltage present, and accidental contact with the positive and negative terminals may result in electric shock injuries. Therefore, when conducting power-on measurements, attention should be paid to the following:

1. Take necessary insulation protection measures (such as wearing insulated gloves).
2. Accompanying personnel must be present to ensure personal safety.

◆ Measuring Instruments



When performing electrical connections and trial operations on the energy storage backup battery, and to ensure that electrical parameters meet requirements, relevant electrical measuring equipment such as multimeters, power meters, etc., should be used. Note the following:

1. Use measuring equipment with a suitable range that conforms to on-site working conditions.
2. Ensure the correct and standardized electrical connections of the instruments to avoid dangers such as electric arcs.

◆ Maintenance and Inspection




When both the energy storage battery and the inverter are turned off, and electrical connections are confirmed to be disconnected, maintenance or inspection operations can be carried out on the energy storage battery cabinet. Pay attention to the following:

1. Ensure that the energy storage battery will not be accidentally re-energized.
2. Use a multimeter to ensure that the energy storage battery is completely de-energized.
3. For parts near potentially live components during operations, use insulating materials for insulation covering or grounding.
4. It is strictly prohibited to perform maintenance or inspection operations on live equipment!

When performing maintenance or inspection on equipment, it must be ensured that at least two personnel are present at the site. Maintenance operations can only be carried out after the equipment is safely de-energized, fully charged, or discharged.

Overview of Main Components

◆ Product configuration list

No.	Image	Name	Qty	No.	Image	Name	Qty
1		Battery	1	5		Communication Cable	1
2		Red-Positive Power Line	1	6		Product User Manual	1
3		Black-negative Power Line	1	7		Certificate of Conformity	1
4		Wall Mount Bracket	1	8		Expansion Bolt	5
This accessory is only for wall-mounted battery (2.56kWh, 5kWh, and 10kWh). It's not included with wheel-type battery.				This accessory is only for wall-mounted battery (2.56kWh, 5kWh, and 10kWh). It's not included with wheel-type battery.			

The product configuration list is subject to change without prior notice.

Product Introduction

◆ Overview

The residential energy storage series lithium battery module integrates high-capacity, high-safety lithium iron phosphate battery cells. It adopts a stacked design with advantages in footprint and vertical space utilization. The module incorporates a high-precision Battery Management System (BMS) unit, monitoring and collecting real-time data on voltage and temperature inside the module. This enables intelligent temperature control at the cell level and smart cell balancing, enhancing system efficiency and battery cycle life. The module features a shock-resistant structure within a cold-rolled sheet metal shell for high safety and reliability, meeting household standards. Additionally, the module is designed for high stability and disturbance resistance, ensuring the safe and reliable operation of the battery system.

◆ Advantages

- The positive electrode material of the battery is lithium iron phosphate (LiFePO₄) material, which has good safety performance, has a cycle life of more than 6,000 times.
- The high-performance intelligent management system is adopted to realize comprehensive state control of battery charging, discharging, floating charging and hibernation, and multi-level protection is set for voltage, current, temperature, etc., so that the battery is always in an ideal state.
- It has a comprehensive monitoring system to monitor the voltage, current, temperature, capacity and working status of the battery.
- The system adopts an intelligent design method to meet the four remote control standards of the national standard: telemetry, remote signaling, remote control, and remote adjustment.
- Built-in intelligent balance module to ensure the capacity consistency of the battery pack during long-term use and prolong the service life.
- The control panel includes status display and alarm devices, which can visually see the working status and alarm information of the battery.
- The system has its own intelligent thermal management device, which can work in a wide temperature range.

Product Appearance

Product Model

The technical parameters of LiFePO4 Battery Energy Storage System are shown in Table 1 below:

Rated Voltage	25.6V/48V/51.2V
Nominal Capacity	100Ah~700Ah
Battery Capacity	2.56kWh~35.84Ah

Control Panel

LiFePO4 Battery Energy Storage System adopts the same control panel structure as Figure 2,




Figure 2 Control Panel Illustration (Reference Picture)

Remark: All LiFePO4 battery energy storage system with wall mounted type, different panel place, LCD display shown in battery pack have same functions.

NOTE: All LiFePO4 battery energy storage systems have the same LCD display functionality inside the battery pack, although the panel location is different.

Port Panel

No.	Name	Function	Notes
1	Negative Terminal Port (+)	Battery Positive Output	
2	Negative Terminal Port (-)	Battery Negative Output	
3	Reset Button (RST)	Battery Reset	Briefly tap and release within 1-3 seconds.
4	RUN&ALM Light	Battery Operation Indicator Light & Battery Alarm Indicator Light	
5	SOC Light	Battery Capacity Indicator Light	
6	Dry Contact	Dry Contact Communication	1.Dry Contact 1 - PIN1 to PIN2: Normally open, closed during fault protection; 2.Dry Contact 2 - PIN3 to PIN4: Normally open, closed during low battery alarm.
7	RS485A	485 Communication Interface	Communication with inverter via RS485
8	CAN	CAN Communication Interface	Communication with inverter via CAN
9	RS232	1.Monitor batteries and modify parameters. 2.Perform software upgrades.	
10	Batt Link/RS485B	Battery parallel connection port	
11	Switch	Power Off External Output Circuit	

Principle and Structure

◆ Operating Principle

Working principle for Residential LiFePO₄ Battery Energy Storage System: Connect battery pack in parallel to the DC output end of the inverter of the energy storage device. When the mains power supply is normal, the inverter module works normally to supply power to the equipment (the load in the figure) and charge the battery pack; when the utility power and photovoltaic power are cut off, the battery pack provides uninterrupted power supply to the inverter to ensure the normal operation of household electricity; When power is turned on again, the battery pack is charged while power is restored to the household loads.

◆ Connection Structure

The connection diagram of residential LiFePO₄ battery energy storage system is shown in Figure 1 below:




Figure 1 Operation Principle Diagram of Battery System

Battery Installation and Wiring

◆ Tool Preparation for Installation

Tools Required: Electric drill, hammer, wrench, M8*60 expansion bolt, Phillips screwdriver, multimeter, insulated gloves, Ethernet cable, power cable.

◆ Installation Preparation

Safety Regulations

The installation, operation and maintenance of LiFePO₄ Battery Energy Storage System should only be carried out by trained and qualified professionals. Before installation and use, please read the safety precautions and related operating procedures of this product carefully. The installation process must strictly abide by the following safety regulations and local safety regulations, otherwise it may cause personal injury or product damage.

- ⌚ Please ensure that the inverter connected to the battery is a qualified power system;
- ⌚ When installing the battery, please ensure that the power system is turned off and the battery pack is turned off;
- ⌚ All power-saving cables must have corresponding insulation measures, and it is strictly forbidden to expose the power cord;
- ⌚ Ensure that the battery and the power system are reliably grounded during installation.

◆ Installation Notes

- When begin to install the battery system, you should pay attention to the following matters:
- Installation space and load bearing. Make sure that there are sufficient fixed components to install the battery system, and to ensure that the battery mounting bracket or the cabinet be strong enough to bear the weight.
- Cable specifications. To ensure that the use of the connection of the power supply line can meet the maximum current requirements of equipment operation.
- Project layout. Ensure the whole construction process of power equipment, batteries and other reasonable layout.
- Wiring layout. Ensure that the wiring reasonable, orderly; and consider the moisture-proof, corrosion prevention.
- The whole installation process should wear anti-static wristband.
- The installation site should be at least two or more peoples to operate.
- Please ensure the installation site safe before installation.

◆ Installation Steps

- Select a suitable solid wall with a thickness greater than 150mm;
- Refer to the fixing distance of the mounting bracket bolts, and mark the hole position on the wall;
- Drill 9 holes according to the hole position, the depth is ≥ 80 mm;
- Mount the M8 expansion bolts in the upper holes and screw on the nuts;

◆ **Installation Steps**

- Fix the mounting bracket on the wall with expansion bolts;
- Under the condition of keeping the battery vertical, raise the battery to a position slightly higher than the mounting bracket, and hang the battery on the mounting bracket.


Step No.	Name	Definition
1	Turn off power supply	The system should be powered off, to ensure that there is no electric in installation process
2	Mechanical installation	1. Mounting lugs installation
		2. Battery fixed installation
3	Electrical installation	1. Grounding cable
		2. Power cable installation
		3. Connecting equipment installation
		4. Communication cable installation
4	Electrical commissioning	Power system commissioning

Step1. Interruption Of Power Supply

Before installation, please ensure the battery is powered off, at the same time, shutdown the equipment which need to connect to the battery.


Step1. Interruption Of Power Supply

- 1.Installation of the mounting bracket. The device is packaged with an attached mounting wall bracket. Before installing the battery, fix the mounting bracket on the wall to ensure that the installation is tight.
- 2.Fixed battery installation. Secure the battery module to the mounting bracket to ensure that the battery pack is securely installed.
- 3.Expansion bolt installation diagram.



NOTICE:


1. In order to avoid electric shock or other injuries, check whether the existing electronic plumbing installation is compliant before drilling.
2. The battery is heavy, please handle it with care, so as not to damage the product or injure the installer.



◆ Electrical Connection


Single Unit Wiring:

- Step 1. Connect the positive and negative terminals of the battery to the positive and negative terminals of the inverter using the power cable.
- Step 2. Complete the battery's grounding connection by using the ground wire.
- Step 3. Connect the RS485A (or CAN) port of the battery to the RS485 (or CAN) communication port of the inverter using the communication cable.



Parallel Wiring:

Step 1. If multiple batteries are used in parallel, manually press the low-voltage switch (ON/OFF) first. Use a multimeter to check if the voltage of each battery is consistent. If consistent, turn off the batteries and proceed with cable connections, as shown in the schematic diagram (using two batteries in parallel as an example).



- Step 1. Connect the positive terminal of the battery using the power cable, and then connect the negative terminal of the battery using the power cable.
- Step 2. Connect the Batt Link/RS485B communication interface of adjacent batteries with communication cables (Batt Link/RS485B battery parallel ports have the same functionality and are not distinguished).
- Step 3. Connect the ground wire to the grounding point for all batteries. There is a ground symbol in the lower-left corner of the battery; attach the ground wire terminal to this point.
- Step 4. Use a standard Category 6 cable. Connect one end to the RS485A (or CAN) communication interface of the battery and the other end to the RS485 (or CAN) interface of the inverter (Note: the pin definition of the inverter communication should match that of the battery; refer to section for battery-to-inverter pin definitions).
- Step 5. Connect the positive terminal (+) of the first battery to the positive terminal interface of the inverter using the power cable. Then, connect the negative terminal (-) of the last battery to the negative terminal interface of the inverter using the power cable.


NOTICE:

- The battery directly connected to the inverter via the communication cable is defined as the master, the others are slave ones.
- The electrical connection illustration is applied for wall mounted type & rack mounted type.

Debugging

◆ RS485 & CAN Port Definition


1. Definition of RS485A port (default baud rate 9600bps) for communication between the battery and the inverter.



NOTICE:

- The default RS485 protocol for the battery is set to Pylontech RS485 (V3.5) protocol. If compatibility with other inverters is needed, it is necessary to communicate through RS232 with the host computer to change the default protocol.

2. Definition of CAN port (default baud rate is 500K) for communication between the battery and the inverter.



NOTICE:

- The battery is factory-set with the default CAN protocol, defaulting to Pylontech CAN (V1.2) protocol. If compatibility with other inverters is required, it is necessary to communicate through RS232 with the upper computer to change the default protocol.

Tip:

- For battery and inverter communication, choose either RS485 or CAN.

◆ UPPER COMPUTER SOFTWARE OPERATION GUIDE

Modifying Battery Parameters and Selecting Inverter Protocol via RS232 Upper Computer.

Tools


- Computer
- USB to RS232 Cable
- Monitoring Software

Operating Steps

- 1.Connect the computer to the battery using a USB to RS232 cable. Plug the USB end into the computer's USB port and the other end into the battery's RS232 port.
- 2.Download and unzip the software package on the computer.
- 3.Open the extracted folder and select the application, as shown below:



- 4.Double-click the above icon to enter the monitoring interface, as shown below:



5. After entering the monitoring interface, click on the top right to open the serial port. Once communication with the battery is established, the left side will display real-time battery information, and the status bar in the lower right will turn green.

The screenshot shows the PbmsTools HS1.0.6 interface with the 'Realtime Monitoring' tab selected. The top navigation bar includes 'Multi Monitoring', 'Memory Info.', 'Parameter Setting', 'System Config.', and 'Export Data'. Below this is a row of numbered tabs from 1 to 15. The main area is divided into several sections:

- Pack Information:** Pack Voltage 52.383 V, Pack Current -3.08 A, SOC 45%, SOH 100%, RemainCapacity 44680 mAh, FullCapacity 100000 mAh, Battery Cycle 1.
- Temperature:** Tcell 1 22.2, Tcell 2 22.1, Tcell 3 22.0, Tcell 4 22.3, MOS_T 24.3, ENV_T 23.4.
- Cell Voltage (mV):** A table showing MaxVolt (3274), MinVolt (3273), and VoltDiff (1) for 16 cells. All cell voltages are 3274 mV.
- Serial Port:** Port COM7, Baud Rate 9600, Pack 1, Pack Qty 1, ADDR 1, Interval(S) 1. Buttons: Close, Try Connect.
- System Status:** CHARGING-ON, CHG-LIMIT-OFF, ACin, DISCHARGING-ON, DISCHARGING, HEATER-OFF, Fully.
- Alarm Status:** None.
- Protect Status:** None.
- Fault Status:** None.
- Switch Control:** CHG Circuit (Close), Sound Alarm (Open), BSG Circuit (Close), LED Alarm (Close), Shutdown (Off).
- Bottom Bar:** VER: P16S100A-31058-1.03, BMS S/N: 310581233701136P, PACK S/N: [redacted], COMM: Normal (green bar), 15:46:07 2023/11/21.

6. After successful communication, enter the password "123456" in the lower right password status bar. Upon correct input, the status bar will turn green.

This screenshot is identical to the previous one, but with the password field in the 'Switch Control' section filled with '123456'. The 'COMM' status bar remains green, indicating successful communication.

7. Left-click on "System Config," as shown below:

PbmTools HSI.0.6 (Protocol code:HS-PACE-232-BP-V1.1)

Realtime Monitoring | Multi Monitoring | Memory Info. | Parameter Setting | **System Config.** | Export Datas

Voltage(mV)
Vref **Calibration**
Pack Voltage **Calibration**

Current(mA)
CHG Current **Calibration** **Resetting**
Zero Current **Calibration** **Resetting**
DSG Current **Calibration** **Resetting**

Cell Number Setting
Cell Number **Setting**

CHG Current Setting
Start Current(A) **Setting** **Read**

Gap Charge Setting
Gap Charge Threshold **Setting**

Capacity(mAH)
DesignCapacity
RemainCapacity
FullCapacity
Read **Write**

Battery Cycle Setting
Battery Cycle 0 **Setting**

Inverter protocol
CAN Protocol
RS485 Protocol
Type
Read **Write**

Manufacture Information
☐ Clear text box after writing
☐ no-repeat BMS S/N 20 **Write**
☐ no-repeat PACK S/N (20) 20 **Write**

VER: P16S100A-31058-1.03 | BMS S/N: 310581233701136P | PACK S/N: | COMM: Normal | 15:48:25 2023/11/21

8. In the middle-right part of the display interface (Inverter Protocol), click "Read" to check if the battery matches the actual inverter brand. If not, click on the CAN or 485 protocol and choose the protocol that matches the inverter, as shown below:

Capacity(mAH)
DesignCapacity
RemainCapacity
FullCapacity
Read **Write**

Battery Cycle Setting
Battery Cycle 0 **Setting**

Inverter protocol
CAN Protocol
RS485 Protocol
Type
Read **Write**

Manufacture Information
☐ Clear text box after writing
☐ no-repeat BMS S/N 20 **Write**
☐ no-repeat PACK S/N (20) 20 **Write**

VER: P16S100A-31058-1.03 | BMS S/N: 310581233701136P | PACK S/N: | COMM: Normal | 15:50:19 2023/11/21

9. After selecting the protocol, click the "Write" button. If the write fails, it indicates that the BMS does not include this inverter protocol, and a program upgrade is required. If the write is successful, click "Read" again to verify the selected protocol.

◆ OPEARATION GUIDANCE FOR BUTTON DISPLAY SCREEN

Protocol Selection for Button Display Screen

By selecting the correct communication protocol version and returning the selected protocol version number to the BMS motherboard program, the user changes the default communication protocol between the BMS and the host computer. The selection menu for this feature is located under the system settings menu directory. The menu structure is shown as follows:



Figure 1



Figure 2



Figure 3



Figure 4

Button Description

1. SW1----MENU, SW2----ENTER, SW4----DOWN, SW5----ESC
2. Each item begins with "" or " -- ", where "" indicates the position of the current cursor. Press DOWN to move the cursor down; If the item ends with ", it indicates that the item has no displayed content. Press ENTER to go to the corresponding page.
3. Press ESC to return to the upper-level directory; In any location, press the MENU key to return to the main menu page. 4) In the hibernation state, press any key to activate the display


Hibernate / Shut Down

In the normal running state, the system enters the hibernation/shutdown state after one minute of operation without pressing a key. In the off/sleep state, operate any key and the display will be activated.

◆ OPEARATION GUIDANCE FOR TOUCHABLE DISPLAY SCREEN

Interface Introduction


By selecting the correct communication protocol version and returning the selected protocol version number to the BMS motherboard program, the user changes the default communication protocol between the BMS and the host computer. The selection menu for this feature is located under the system settings menu directory. The menu structure is shown as follows:



Primary Menu

Icon Description:

	Click the primary menu icon to enter the main menu HOME interface
	Click the Main status icon to enter the Main State interface
	Click to enter the Parallel Data interface



HOME Page

In normal operation, the system will enter the sleep/shutdown state after 3 minutes of operation without key. In the off/sleep state, click any location of the color screen, the display will be activated, and enter the status interface before the screen.

Menu Structure

- Menu
 - Min state page (Main Status Interface)
 - SOC(Total) SOC(each pack)
 - Current Current
 - Voltage Voltage
 - BMS INFO BMS INFO
 - Warranty Warranty
 - Parral data Parral data
- HOME (Main Page)
 - PACK Info (pack -cell data)
 - Voltage (Cell01 voltage.....Cell016 voltage)
 - Temperature (NT1. NT1.....Mos_T.ENV_T)
 - BMS Status
 - Warning
 - Protect
 - Fault
 - Protect
 - PROTOCOL(Protocol selection)
 - CAN
 - ◆GOOD WE PROTOCOL
 - ◆LV BMS Protocol(CAN) for Solar Inverter Family EN_V 1.5
 - ◆PYLON PROTOCOL 2.0
 - ◆Pylon CAN bus protocol V 2.0.420211122
 - ◆SMA PROTOCOL
 - ◆SMAF SS-Connecting Bat-TI-en-20W
 - ◆GROW ATT_PROTOCOL
 - ◆Growatt BMS CAN-Bus-protocol-low-voltage
 - RS485
 - ◆USER_485_VOLTRON
 - ◆Voltronic Inverter and BMS 485 communication protocol 20200325(1)
 - ◆PYLON
 - ◆RS 485-protocol-pylon-low-voltag
 - ◆Luxpowertek Battery Protocol RS 485_V 01
 - SYSTEM
 - Language select
 - ◆English
 - ◆Chinese Simplified
 - ◆Chinese Traditional
 - PACK SN
 - BLUETOOTH SN

Note: The protocol list is read from the BMS motherboard, and the following is a case based on the built-in list of each BMS motherboard ; Changing the protocol, the first time you need to enter the permission password, the initial password is 123456, exit the protocol interface, the permission takes effect, modify the protocol again, need to verify the permission again.

◆ POWER-ON SEQUENCE

After the completion of the connections between the inverter, battery, and mains power, start each battery one by one. Then, turn on the inverter. After the battery startup, check if the communication between the inverter and the battery is normal. If the battery data is successfully uploaded to the inverter, it indicates successful communication between the inverter and the battery.

◆ COMMON ISSUES AND SOLUTIONS

No.	Fault Symptoms	Cause Analysis	Solution
1	No DC Output	Battery Voltage Too Low, Protection Activated	Startup after Charging Activation
2	Short Power Supply Time	Insufficient Battery Capacity or Failure to Reach Full Charge	Confirm Maintenance or Replace Battery
3	Battery Cannot Reach Full Charge	DC Voltage Output from Power System Lower than Minimum Charging Voltage	Adjust Device's DC Output Voltage to Suitable Charging Voltage for Battery
4	Unstable Battery Output Voltage with Significant Fluctuations	Interference with Management System Operation	Restart the System
5	Temperature Monitoring Too Low	Damage to Temperature-Sensing Crystal Head	Replace the Collection Line with a Temperature-Sensing Crystal Head
6	Unable to Charge	Single Cell Protection Activated upon Full Battery Charge	Discharge Protection Removal
7	MOS temperature abnormal	MOS tube damaged	Replace BMS
8	Discharge overcurrent protection	Inverter power exceeds limit	Match the number of batteries according to the inverter power value

◆ Inverter Matching Information

Inverter Brand	LOGO	Communication Method	Inverter Communication Pin	Battery Communication Pin	Remarks
Voltronic Power		RS485	PIN5:RS485A PIN3:RS485B	PIN2/7:RS485A PIN1/8:RS485B	1.Default Battery Protocol Matching 2.Customized Network Cable
VICTRON		CAN	PIN7:CANH PIN8:CANL	PIN4:CANH PIN5:CANL	1.Battery Protocol Change 2.Customized Network Cable
Growatt		RS485	PIN2:RS485A PIN1:RS485B	PIN2/7:RS485A PIN1/8:RS485B	1.Default Battery Protocol Matching
		CAN	PIN4:CANH PIN5:CANL	PIN4:CANH PIN5:CANL	2.Inverter Protocol Setting Option 2
PYLONTECH		RS485	PIN7:RS485A PIN8:RS485B	PIN2/7:RS485A PIN1/8:RS485B	Default Battery Protocol Matching
GOODWE		CAN	PIN4:CANH PIN5:CANL	PIN4:CANH PIN5:CANL	Default Battery Protocol Matching
LUXPOWER		RS485	PIN2:RS485A PIN1:RS485B	PIN2/7:RS485A PIN1/8:RS485B	1.Battery Protocol Change 2.Customized Network Cable
SOFAR		CAN	PIN1:CANH PIN2:CANL	PIN4:CANH PIN5:CANL	1.Battery Protocol Change 2.Customized Network Cable
SRNE		RS485	PIN7:RS485A PIN8:RS485B	PIN2/7:RS485A PIN1/8:RS485B	1.Default Battery Protocol Matching 2.Inverter Protocol Setting PYL
Deye		RS485	PIN7:RS485A PIN8:RS485B	PIN2/7:RS485A PIN1/8:RS485B	Default Battery Protocol Matching
		CAN	PIN4:CANH PIN5:CANL	PIN4:CANH PIN5:CANL	
MEGAREVO		CAN	PIN4:CANH PIN5:CANL	PIN4:CANH PIN5:CANL	Default Battery Protocol Matching
MUST		CAN	PIN6:CANH PIN5:CANL	PIN4:CANH PIN5:CANL	1.Battery Protocol Change 2.Customized Network Cable
SMA		CAN	PIN4:CANH PIN5:CANL	PIN4:CANH PIN5:CAN	Battery Protocol Change

Maintenance

1. Do not immerse the battery in water. When not in use, store it in a cool and dry environment.
2. Do not throw the battery into the fire or heat it externally to avoid explosion or other hazards.
3. Do not invert the positive and negative poles of the battery. Never connect the battery directly to a power outlet, and prohibit short-circuiting the positive and negative poles.
4. Do not mix batteries from different manufacturers, different kinds, types, or different ages.
5. Do not use batteries that show signs of heating, swelling, deformation, or leakage in charging or discharging devices.
6. Prohibit piercing the battery with nails or other sharp objects, as well as throwing, stepping on, hitting, or impacting the battery.
7. Prohibit disassembling or dismantling the battery and its components. Any damage caused by unauthorized disassembly or repair will not be the responsibility of our company.
8. The battery undergoes strict inspection before leaving the factory. If customers find signs of heating, swelling, or unusual odors, do not use it and return it to the factory immediately.
9. For long-term storage, to ensure optimal battery performance, perform a charge-discharge cycle every three months and ensure a storage charge of 40%~60%.
10. Use the battery within the specified temperature range as stated in the specification.
11. Follow the specified power-up sequence for both the battery and the inverter.
12. The recommended load power for the battery should not exceed the maximum continuous discharge current of the battery (100A).
13. If the battery is left unused for more than 3 months, it needs manual charging periodically to prevent complete discharge.

NOTE:

- In case of specific technical issues or situations not mentioned above, please contact technical support promptly.

PACEEX BMS APP user manual

Catalogue

1、Download and install.....	1
2、APP dynamic permission.....	1
3、Control method.....	2
4、Local Control (BLE).....	3
5、telecontrol.....	4
5.1, Account registration and login.....	4
5.2, List of equipment.....	5
5.3, Equipment added.....	5
5.3.1: The wifi module is put back in the factory.....	5
5.3.2: Click "Add" and "+" to enter the search page and search for the device.....	6
5.3.3: Fill in the distribution network information.....	7
5.3.4: Execute distribution network operation.....	8
5.3.5: Distribution network results.....	9
5.4, Device editor.....	10
5.5, Device sharing.....	11
5.6, Device control.....	12
5.7, OTA upgrade.....	13
5.8, Account exit and logout.....	15

Manual

1、Download and install

According to the mobile phone system, select the download link:

Android entrance: Mobilephones that supportGMS can downloadPACEEXApp through GooglePlay Store, andAndroid phones that do not supportGMS can install APK directly.


<https://play.google.com/store/apps/details?id=com.paicheng.bms>

iOS entrance: Search for PACEEX downloads in the App Store

<https://apps.apple.com/cn/app/6461723294>

2、APP dynamic permission

Install the APP, click the start button and start smoothly. For the first start, you will request the user to confirm and authorize the following authority: Camera permission: Add wifi devices in remote control Location permission: search for nearby Bluetooth devices in local control and identify current network information in remote control Equipment status information: to detect the operation status of the equipment Photos and audio: The code scanning interface in the remote control system can directly identify the local photo album



3、Control method


Local control: BLE Bluetooth communication, directly search for the nearby Bluetooth signal, a pair of continuous connection, control devices, no account login, do not do binding records, that is, ready to use Remote

control: WiFi communication, which realizes the purpose of controlling the device rather than in the same geographical location. It requires account registration and login, records the binding between the account and the device, and requires distribution network operation.



4、Local Control (BLE)

When the device is in the distribution network state, click the local control button to search the device on the local control page, and click the device to enter the device control page




5、telecontrol

5.1, Account registration and login

Registration: Create the new account by means of email account, password and verification code. Note: Please select the real country and region according to the actual situation. This is very important. Once selected and created successfully, the devices added through the account distribution network will automatically connect to the server node with the same account

Login: Log in with the registered account number and password

Forget your password: You can reset your password through your email number




5.2, List of equipment

5.3, Equipment added

5.3.1: The wifi module is put back in the factory


The wifi module restores the factory so that the device is in a discoverable state :

Long press the reset button 10-13 s, the specific operation of the LED lamp is shown as : long press the button to make the water lamp run one.



5.3.2: Click "Add" and "+" to enter the search page and search for the device

Note: This step requires the phone to open the "Bluetooth", "Positioning" and "WiFi" functions, otherwise the search and subsequent distribution network operation cannot be completed



5.3.3: Fill in the distribution network information

Click the device found in 5.3.2, jump to the distribution network information page, fill in the WiFi account and password of the device to be connected, or change the WiFi. After confirming that the password is correct, click "Next" to enter the distribution network waiting page

Note: The mobile phone should be connected to the WiFi first, and the module only supports 2.4G WiFi, please identify it by yourself

4:08 PM 0.3KB/s

< WiFi Connection

Devices to be added:

18:B9:05:DA:30:00

Select 2.4GHz WiFi Input


Redmi_AF36

12345678

NEXT


5.3.4: Execute distribution network operation

APP and device will automatically perform "Connect device", "Configure network", "device cloud" and "bind device" operations. Please wait patiently




5.3.5: Distribution network results

When the distribution network is over, it will jump to the page, click Save to successfully add and automatically jump back to the device list page; If the network fails, please follow the prompts of the APP, and start from step 5.3.1 after inspection. If the network still fails for many times, please save the error page and contact the after-sales personnel!



5.4, Device editor

Long press the device item, and the edit menu will pop up at the bottom
Rename: Modify device nickname to use
Delete: unbinding with the device, the next use need to scan the code or add the network



5.5, Device sharing

Long press the device item, when you are the device administrator (the first account bound to the first distribution network), the device can generate a QR code for other users to scan the code to add.


Note: Non-administrators cannot share twice. The QR code generated each time can only be scanned once, and the time of scanning the code is limited (30 minutes).



5.6, Device control


According to the functions supported by serial port protocol 0.0.9, except for the protocol itself, the summary interface, basic data, voltage and temperature, state data, historical data, parameter setting, equipment information, general setting, etc





5.7, OTA upgrade

When there is an updated version of firmware in the background, the APP clicksona device to popup the upgrade popup, click upgrade immediately, and the firmware will be upgraded. Click the next time to enter the device parameters display, Settings and other pages.



5.8, Account exit and logout

Account exit: after exit, you can switch to other accounts for login Account cancellation:
Once cancelled, all the information and binding relationship of the account will be cleared, and you need to be re-registered next time

